



# AUTOMAGIC SILVER MACHINE

## QUAKE MACHINE

### MKII



Connection for an external  
AC-Adapter 9V DC.

Parallel Output 2

**New! Auto Magic  
Revolution Sensor,  
touch sensitive.**

Technical Data:  
Power Supply Specifications:  
-9 V DC Battery  
-9 - 18 V DC AC-Adapter  
Polarity:  
tip negative /barrel positive.  
Resting Power Requirements  
2.68 mA  
Silver Machine:  
Earth-Bottom: 207-3600 Hz.  
Quake Machine:  
Earth-Bottom: 41-2350 Hz.  
Quake: 0,8 Q - 6,0 Q  
Mode Select:  
-classic: Wah  
-modern: Mixed-Mode

Guarantee:  
EU: 24 Months  
USA: 12 Months

## **Silver Machine, Quake Machine MKII.**

**Operating manual Mod. 2012** The Silver Machine combines the best sound characteristics of its forerunners with the most innovative new developments to create a truly first class wah wah effect. The pedal is unique thanks to its "AutoMagic" functionality and its variable filter which provides 12 different sounds.

Activation the "AutoMagic Revolution Sensor"

The Wah effect is turned on via the Sensor on the pedal. No more click type switch at the end of the pedal travel.

### **New!**

From model 2005 on, the Wah effect can be turned on permanently, to enable use of the pedal as a selectable filter.

### **Mode Select, Modern, Clean:**

The mini toggle switches between the "Classic" and "Modern" mode. In "Classic" mode the pedal works like a regular wah, it passes the effected ( wet) signal only. ( 100% wet).

In "Modern" mode, the pedal allows for an effect/original signal ( wet/dry) mix.

### **Earth:**

The "Earth" control is represented by a three-way rotary switch that provides a choice of three frequency ranges.

### **Silver Machine:      Quake Machine:**

- |                   |                   |
|-------------------|-------------------|
| 1. 207 - 3570 Hz. | 1. 41 - 930 Hz.   |
| 2. 360 - 3570 Hz. | 2. 60 - 930 Hz.   |
| 3. 256 - 1750 Hz. | 3. 236 - 2350 Hz. |

### **Quake:**


Another rotary, this time with four positions controls the band-width (Q Factor) of the filter and thus of the wah-wah effect. The control alters the intensity of the effect.

### **Fine Tuning:**

The Silver Machine can be adlusted to suit your tastes. This involves opening the housing to reveal the circuit board. On the board is a trim potentiometer marked "T1 Mix". This controls the ratio of the effects signal to the original in "Modern" mode.

**New** "T2" controls the level of the Wah Sound.

Be careful not to dislodge the battery cable when adjusting this trimmer.



### **Changing the battery**

The Silver Machine's battery is located in a compartment recessed into the underside of the housing and accessible from outside it. In addition a power supply socket for 9 to 18 Volt DC (max) is also included. With a current consumption of only 2.68 mA, a good 9V battery will last in the Silver Machine for well over 100 hours.

### **Care and maintenance**

Just as with any other electronic device subjected to use under high-stress conditions, the Silver Machine benefits from good care and maintenance.

Occasionally the pedal itself should be carefully readjusted using two 8 mm Allen keys. It is also recommended that the fader should occasionally be sprayed with a cleaning agent. Use only Deoxit D5 or Kontakt 60 Plus another Spray dont work.

For this purpose a small service hole is provided on the underside of the device. The spray tube should carefully be inserted into the fader beneath this hole and the equipment should then be wiped dry.

The equipment should not be stored in damp conditions to prevent the oxidation of sensitive electronic componnts.

The housing is stainless steel and requires no special maintenance.

### **Important!**

If you get during the effect mode no signal ,open the housing and control the blue multi pin cable and connect it for a second time with the socket.

Pressure should not be put on the Activator when it is in storage since this will considerably reduce the life-expectancy of the equipment.

**Garantee Europe:** 24 months, not including consumables.